



FlexiDry[®]
Global Ltd
INNOVATORS IN SCREED SCIENCE

Mixing Instructions – F0

Mixing of Material

Materials should be mixed in a forced action mixer such as a screed pump or pan mix. The correct dosage of FlexiDry should be dispersed in a water bucket and added to the correct sand and cement grades (see below). Mixing time should be approximately 2 minutes, ensuring a good distribution of product and water, adjusted to facilitate trowelling. Materials to be read in conjunction with BS8204:1 2003 and relevant codes of practice.

Dosage

F0 (3 days): 175ml of FlexiDry per 25kg of Cement

Compatible Cements

CEM1: CEM1 32,5 R or CEM1 42,5 N (sd)

