

F.511

FLOORMASTER RELEASE ADHESIVE



F.511 Floormaster release adhesive is a water based release adhesive suitable for installation of carpets and tiles where later removal may be a requirement. The adhesive forms a strong bond yet normally allows the floorcovering and adhesive to be cleanly removed from the substrate.

- Saves time as laid whilst adhesive is wet
- Strong Bond
- Good Coverage

Uses

F.511 is suitable for the bonding of:

CARPET: Woven, jute backed, heavy duty latex foam backed, unitary, PVC, polypropylene and textile backed. It is also suitable for mineral felt backed floorcoverings.

VINYL FLOORCOVERINGS: Will bond most PVC sheet (including cushion types) and tiles.

Sub-Floors

Concrete bases, cement screed, anhydrite screed, smoothing & levelling underlayment, flooring grade chipboard, hardboard, plywood.

Specification

Adhesive type:	
Colour:	Off White.
Flashpoint:	Non-flammable.
Coverage:	If applied using a roller or notched trowel as described 90-135m ² per 15 Litre bucket.
Application Temperature:	+5°C – +30°C.
Working Time:	Approx. 1 hour, depending on temperature, humidity & subfloor.
Storage & Shelf Life:	12 months in original, unopened container stored between +10°C and +30°C.
Container sizes:	15 Litre plastic bucket.

Directions for Use

Before starting work using F.511 Floormaster release Adhesive, please refer to the section headed "Handling Precautions" and to the separate Safety Data Sheet.

Preparation

Subfloors should be sound, clean, dry and free from rising damp, grease, dust or any loose material. Cementitious surfaces should have a relative humidity of less than 75%. To allow easy removal of adhesive and floorcovering the subfloor should be primed with a suitable primer, which should be allowed to dry before the adhesive is applied. Underfloor heating should be switched off 48 hours before and after laying the floorcovering, then gradually increased after this period.

Preparation should be in accordance with the recommendations of BS8203 (Sheet & Tile Flooring) and BS5325 (Installation of Textile Floorcoverings).

If in doubt, consult the relevant CFA Manual for Floor Preparation.

Application

Apply and even coat of adhesive to the subfloor using a roller or notched trowel with 2.4mm x 4.75mm centres, then press the floorcovering firmly into the adhesive. The floorcovering should be laid whilst the adhesive is still wet. Apply an even pressure using a 60-75 kg roller to ensure overall contact. Approximately 2 hours after, roll again.

Cleaning

Clean tools with warm water containing a little detergent whilst the adhesive is still wet.

DO NOT USE SOLVENTS TO CLEAN THE SKIN.

Handling Precautions

In case of contact with eyes, rinse immediately with plenty of water and seek medical advice. After contact with skin, wash immediately with plenty of water. Seek medical attention if irritation persists.

KEEP OUT OF REACH OF CHILDREN

This product data sheet is provided for guidance only. For further information and advice on application, or if in any doubt as to the suitability of the product for the installation, please contact our Technical Department for advice.

