

Ely – Norwich

Resignalling

Ely North Junction and Hethersett Ground Frame



Contents

Legend

Page 3 and 4

Queen Adelaide L.C. – Hethersett G.F.

Page 5 Queen Adelaide L.C.

Page 6 Mile End L.C.

Page 7 Shippea Hill Station

Page 8 The Drove L.C. Bryants L.C.

Page 9 Lakenheath Station

Page 10 Hiams Fen House L.C.

Page 11 Brandon Station

Page 12 Santon L.C.

Page 13 Two Mile Bottom L.C.

Page 14 Thetford Station

Page 15 Gooderham's L.C.

Page 16 Hockham Road L.C.

Page 17 Harling Road Station

Page 18 Eccles Road Station

Page 19 Hargham L.C.

Page 20 Attleborough Station

Page 21 M.P. 109-111

Page 22 Spooner Row Station

Page 23 Wymondham Station


Page 24 Hethersett G.F.

Table of Routes

Page 25 Down and Up

Legend


Colour Light Signals



Semaphore Signals




Ground Position Light Signals




Banner Repeaters



Shunting Signals




Signal Plates



Limit of Shunt Indicators








Radio Electric Token Block Signals





Legend

General Information



Permanent Speed Restrictions




DM Down Main
UM Up Main

72


Note:
All Telephones, Signals
and Level Crossings
controlled by Cambridge S.B.
unless otherwise shown

73



Note:
CA778 is a
Right Hand Side Signal


74



DM Down Main
UM Up Main

Note:
All Telephones, Signals
and Level Crossings
controlled by Cambridge S.B.
unless otherwise shown


Note:  = LED Head Signal




DM Down Main
UM Up Main

Note:
All Telephones, Signals
and Level Crossings
controlled by Cambridge S.B.
unless otherwise shown

Note: **D** = LED Head Signal

T.A.P.M.184.0.0.1 EA1580 Stage 1
TCB
Cambridge SB (EN) 




DM Down Main
UM Up Main

Note:
All Telephones, Signals
and Level Crossings
controlled by Cambridge S.B.
unless otherwise shown

Note: **D** = LED Head Signal

T.A.P.M.184.0.0.0.1 EA1580 Stage 1

TCB
Cambridge SB (EN) 



DM Down Main
UM Up Main


82

Note:
All Telephones, Signals
and Level Crossings
controlled by Cambridge S.B.
unless otherwise shown

Note: **D** = LED Head Signal

T.A.P.M.184.0.0.0.1 EA1580 Stage 1

TCB
Cambridge SB (EN) 




DM Down Main
UM Up Main

Note:
All Telephones, Signals
and Level Crossings
controlled by Cambridge S.B.
unless otherwise shown

Note:  = LED Head Signal

* = See Table of Routes




DM Down Main
UM Up Main

Note:
All Telephones, Signals
and Level Crossings
controlled by Cambridge S.B.
unless otherwise shown

Note:  = LED Head Signal

* = See Table of Routes




Note:
EN8063, EN8064, EN8078 and EN8084
are Right Hand Side Signals

DM Down Main
UM Up Main

Note:
All Telephones, Signals
and Level Crossings
controlled by Cambridge S.B.
unless otherwise shown

Note: **D** = LED Head Signal

TCB
Cambridge SB (EN) 




TCB
Cambridge SB (EN) 

DM Down Main
UM Up Main

Note:
All Telephones, Signals
and Level Crossings
controlled by Cambridge S.B.
unless otherwise shown

Note:  = LED Head Signal



DM Down Main
UM Up Main

Note:
All Telephones, Signals
and Level Crossings
controlled by Cambridge S.B.
unless otherwise shown


Note:  = LED Head Signal

N9
60

93

267 ↑ 1100


1100 Y 281



Note:
EN8103, EN8113 and EN8114
are Right Hand Side Signals

94

281 ↑ 990



End of Area of
Low Adhesion

Area of Known
Low Adhesion

N10
60

DM Down Main
UM Up Main

Note:
All Telephones, Signals
and Level Crossings
controlled by Cambridge S.B.
unless otherwise shown

Note:  = LED Head Signal


95

990  347

347  Level  287

287  200


N10
60



96

200  291


291  230



DM Down Main
UM Up Main

Note:
All Telephones, Signals
and Level Crossings
controlled by Cambridge S.B.
unless otherwise shown

Note:  = LED Head Signal




Note: X50 Sign for
Hockham Road L.C.

DM Down Main
UM Up Main

Note:
All Telephones, Signals
and Level Crossings
controlled by Cambridge S.B.
unless otherwise shown

Note:  = LED Head Signal



Note: X50 Sign for
Hockham Road L.C.

Proposed Limit of Stage 1
Proposed Limit of Stage 2

DM Down Main
UM Up Main


Note:
All Telephones, Signals and Level Crossings controlled by Cambridge S.B. unless otherwise shown

Note: **D** = LED Head Signal


* = See Table of Routes

TCB
Cambridge SB (EN) 

103



104




Note:
EN8153 and EN8158 are Right Hand Side Signals

DM Down Main
UM Up Main

Note:
All Telephones, Signals
and Level Crossings
controlled by Cambridge S.B.
unless otherwise shown

Note:  = LED Head Signal




DM Down Main
UM Up Main

107

Note:
All Telephones, Signals and Level Crossings controlled by Cambridge S.B. unless otherwise shown

Note:  = LED Head Signal

108



Note
D.R.A. 


DM Down Main
UM Up Main


109

Note:
All Telephones, Signals and Level Crossings controlled by Cambridge S.B. unless otherwise shown

Note:  = LED Head Signal

T.A.P.M.184.0.0.0.1 EA1580 Stage 2

TCB
Cambridge SB (EN) 




DM Down Main
UM Up Main

Note:
All Telephones, Signals and Level Crossings controlled by Cambridge S.B. unless otherwise shown

Note: **D** = LED Head Signal

T.A.P.M.184.0.0.0.1 EA1580 Stage 2


TCB
Cambridge SB (EN) 



DM Down Main
UM Up Main


Note:  = LED Head Signal

Note:
All Telephones, Signals
and Level Crossings
controlled by Cambridge S.B.
unless otherwise shown




Note:
EN8221, EN8223 and EN8236
are Right Hand Side Signals

115



DM Down Main
UM Up Main

TCB
Cambridge SB (EN) 
Colchester SB (CO)




Table of Routes

The following lists of signal routes show all routes from

- signals from which there is more than one route
- signals which are capable of giving any route indications
- all position-light signals

'M' indicates a main aspect

'PL' indicates Position Light Shunt aspect

Items in the '**Route Indication Displayed**' column specify a route indicator display or an illuminated Junction Indicator position

Ely North Junction – Hethersett Ground Frame

Down Direction

Signal Number	Aspect	Route Indication Displayed	Route	Exit Signal
EN8061	M	Pos.1	Down Goods Loop	EN8081
	PL	L	Down Goods Loop	EN8081
	M	Nil	Down Main	EN8083
EN8063	PL	L	Down Goods Loop	EN8081
	PL	DM	Down Main	EN8083
EN8069	PL	Nil	Down Goods Loop	EN8081
EN8103	PL	UM	Up Main	EN8113
	PL	S	Siding	– TSDG
EN8153	PL	Nil	Down Main	EN8167
EN8155	PL	Nil	Down Main	EN8167
EN8223	PL	D	Down Main	EN8237
	PL	S	Up Siding	– WUSG
EN8225	PL	Nil	Down Main	EN8237

Up Direction

Signal Number	Aspect	Route Indication Displayed	Route	Exit Signal
EN8236	M	U	Up Main	EN8198
	PL	Nil	Down Sidings	– WDSG
	M	B	Down Single Line	M.N.R
EN8158	PL	UM	Up Main	EN8148
	PL	ES	Exchange Sidings	– ESDG
EN8114	PL	Nil	Up Main	EN8110
EN8086	M	Nil	Up Main	EN8066
	M	Pos.4	Down Main (Up Direction)	EN8064
EN8084	PL	DM	Down Main	EN8064
	PL	L	Down Goods Loop	EN8078
EN8078	PL	DM	Down Main	EN8064
	PL	S	Down Siding	– TSDG

COPYRIGHT

Gioconda Limited Unit 10 Woodfalls Gravelly Ways
Laddingford Kent ME18 6DA

Telephone 01622 872512 email mail@gioconda.co.uk www.gioconda.co.uk