



Maintenance of Natural Stone Tile floors

Routine Cleaning

Once your Amarestone floor has been properly sealed during installation with one of our recommended specialist Fila stone impregnators, you will find it easy to keep clean.

Mopping the floor with a very dilute solution of Fila Cleaner in clean water is generally enough for regular maintenance. The **Filacleaner** will not remove any protective wax or sealer or damage the surface of the stone.

For normal maintenance, dilute 1 part of Fila Cleaner with 200 parts of clean water. At this dilution, one litre of cleaner will be sufficient for about 40 washes and the floor will not need rinsing after cleaning.

For more stubborn marks, use a more concentrated solution of Fila Cleaner and rinse with clean water after mopping.

If the tiles have been waxed, occasionally adding a little liquid wax to the washing water will help to maintain the required sheen and provide extra protection.

It is important to not use "supermarket" floor cleaners or bleach as these are likely to etch the surface of the stone, making future maintenance more difficult and potentially spoiling the look of your floor.

Special Maintenance

In exceptional circumstances where the stone cannot be cleaned as described above, e.g. where the stone has been stained prior to sealing, we offer various specialist Fila products for the removal of spots, stains and grease marks.

A wide range of Fila sealers, waxes and cleaners is available from Amarestone.

For further free technical advice, please call Amarestone on 0845 260 80 70.