



**Basic Wiring for Split Chiller Control**



**Inline fuseholder 5amp MAX**  
installed in Chiller Control supply  
**Inline fuseholder 3amp MAX**  
installed in mains supply

Temperature sensor (Indoor)