

TO PROGRAMME 433 ROOM UNIT NUMBER:

- Press and hold the Reset button until step 4.
- Press Emergency once
- Press Assistance once
- Let go of the Reset button
- Press the Reset button once
- Now the unit is in programming mode. For Hundreds press the Emergency button.
- For Ten's press the Assistance button
- For units, press the Reset button
- When the new number is programmed press the yellow Call button to store the new number.
- Press Reset to clear the unit and its now ready to work.
- E.g. for 123 after step 5 press: Emergency once, Assistance twice and Reset three times.

TO PROGRAMME 433 ROOM UNIT HOUSE CODE NUMBER:

(Please find out your House Code setting before attempting this section)

- Press and hold the Reset button until step 4.
- Press Emergency once
- Press Assistance once
- Let go of the Reset button
- Press the Assistance button twice
- Now the unit is in programming House code mode.
- Press Reset the amount of times you require the House code.
- Press Assistance once. A double bleep will be heard confirming new settings.