



## WET-POUR REPAIR KITS

### Pricing

- 4 Kilo Black Repair Kit:  
£29.50 each + Carriage
- 5 Kilo Colour Repair Kit:  
£38.50 each + Carriage

Prices are + vat

Discounts for larger order quantities, please contact us for more information.

## WET-POUR REPAIR KITS

Soft Surfaces would like to introduce their new easy to use [wet-pour safety surfacing repair kits](#). Each kit contains all the materials required to repair small damaged areas of wet-pour safety surfacing.



The kits have been prepared to mix the ingredients together to repair an area of up to 0.5 square meters at a depth of 15mm. Each kit contains EPDM rubber granules in any colour required, single part moisture curing polyurethane binder (SSPT 46) and single part moisture curing (SSPrimer). The polyurethane primer (SSPrimer) comes with brush applicator. Also included is a pair of latex gloves. The bucket the kit is supplied in also acts as the mixing container. Full installation instruction is on each mixing bucket.

The only additional items requires to complete the repair is a Stanley knife or similar, a float or screed, a stirrer and some soapy water to coat the float or screed.

All [wetpour](#) colour repair kits are generally in stock at all times and shipment or collection can be made to suit your requirements.

*Please email us for price request, remember to include your full contact details, in case we have any questions.*

Water House, 35 Water Lane, Wilmslow, Cheshire, SK9 5AR

Tel: 01625 445 760 Fax: 01625 525 619

[info@softsurfaces.co.uk](mailto:info@softsurfaces.co.uk)

[www.softsurfaces.co.uk](http://www.softsurfaces.co.uk)

# Soft Surfaces



SPORTS AND SAFETY SURFACES

## WET-POUR REPAIR KITS

### Pricing

- 4 Kilo Black Repair Kit:  
£29.50 each + Carriage
- 5 Kilo Colour Repair Kit:  
£38.50 each + Carriage

Prices are + vat

Discounts for larger order quantities, please contact us for more information.


## INSTRUCTIONS




**Remove all loose material from damaged area**



**Mark area to be cut back**



**Cut back area neatly with knife to give a clean edge**



**Remove damaged area**



**Ensure all materials are close to hand**



**Apply some primer to all edges to act as a bonding agent**




**Mix the granules and polyurethane together in the bucket**




**Pour mixed granules into area**




**Overfill the hole to allow for compression**



**Screed and compress granules into area**



**Ensure granules are level and in line with existing surface**



**Leave area to cure**

Water House, 35 Water Lane, Wilmslow, Cheshire, SK9 5AR

Tel: 01625 445 760 Fax: 01625 525 619

[info@softsurfaces.co.uk](mailto:info@softsurfaces.co.uk)

[www.softsurfaces.co.uk](http://www.softsurfaces.co.uk)