



## Wet-Pour Depths and Critical Fall Heights (CFH) Page 121

### Sub Base - Tarmac

20mm Wearing Course	CFH 1.00m	<p><b>20mm</b></p> <p>20mm comprises of a 20mm wearing course layer. This offers a sufficient surface for equipment with a CFH of 1.00m or less when installed on to tarmac.</p>
15mm Wearing Course 25mm Base Layer	CFH 1.25m	<p><b>40mm</b></p> <p>40mm <a href="#">wet pour</a> safety surfacing comprises of a 15mm wearing course layer and a 25mm base layer. This offers a sufficient surface for equipment with a CFH of 1.25m or less when installed on to tarmac.</p>
15mm Wearing Course 35mm Base Layer	CFH 1.50m	<p><b>50mm</b></p> <p>50mm comprises of a 15mm wearing course layer and a 35mm base layer. This offers a sufficient surface for equipment with a CFH of 1.50m or less when installed on to tarmac.</p>
15mm Wearing Course 45mm Base Layer	CFH 1.75m	<p><b>60mm</b></p> <p>60mm comprises of a 15mm wearing course layer and a 45mm base layer. This offers a sufficient surface for equipment with a CFH of 1.75m or less when installed on to tarmac.</p>
15mm Wearing Course 65mm Base Layer	CFH 2.20m	<p><b>80mm</b></p> <p>80mm wetpour <a href="#">safety surface</a> comprises of a 15mm wearing course layer and a 65mm base layer. This offers a sufficient surface for equipment with a CFH of 2.20m or less when installed on to tarmac.</p>
15mm Wearing Course 95mm Base Layer	CFH 3.00m	<p><b>110mm</b></p> <p>110mm comprises of a 15mm wearing course layer and a 95mm base layer. This offers a sufficient surface for equipment with a CFH of 3.00m or less when installed on to tarmac</p> <p><i>Please use this table for guide purposes only. CFH ratings may vary depending on the sub base they are laid over. We would be only too pleased to clarify your specific site requirements. Wet-pour surfacing is a porous system and so consideration should be give to site drainage requirements.</i></p>

