

Total Cubicle Solutions

Volante Range

Cubicles • Vanity Units • IPS Units



Volante Range

A stylish Toilet Cubicle system featuring attractive colour combinations and durable components.

This range is available with optional postformed pilasters and features robust bolt through fittings for the demanding applications. In addition, the panels are finished in matching 2mm PVC edges with round leg fittings adding to the overall athletics of this range

Volante is offered with satin anodized aluminium fittings as standard but can be customised with powder coated variants. The Volante range is also complimented with matching Vanity units & Pre-built IPS units



Volante is suitable for medium traffic areas and provides an attractive, cost effective solution for:

- Office Blocks
- Workshops
- Factories
- Nightclubs & Bars

To comply with new Building Regulations, part M, Total Cubicle Solutions has added enlarged and ambulant cubicle options to the Volante range. Together with our service promise, you are now in the position to specify, with confidence, a stunning washroom installation for any market.


Total Cubicle Solutions offer a fast turnaround for the tightest of deadlines and having built up a reputation for superb after sales support, our goal is to supply your toilet cubicles with the minimum of fuss, ensuring that from the start to finish, your project runs smoothly.

All this, and the added reassurance that you are dealing with people with over 75 years experience in the industry.




Toilet Cubicle Layout Options


Single Cubicle (SI)




Free Standing (FS)



Open Ended (OE)



Between Walls (BW)



Units 5-7, Luton Street
Liverpool
L5 9XR

T: 0844 800 7785

F: 0844 800 7738

E: sales@totalcubicles.co.uk

Fittings and Accessories

Volantes fittings are built to stand the test of time. They come in an attractive satin anodized finish to contrast with the Volante Range colour options.

TCHIN13 / TCHIN19



TCCHA13 / TCCHA19



TCTRHold




TCRL13 / TCRL19



TCCHOOK



TCCH2MB / TCCH4MB




TCIDK



TCODK



TCLOCK13 / TCLOCK19



DOOR BUFFER




Units 5-7, Luton Street
Liverpool
L5 9XR

T: 0844 800 7785
F: 0844 800 7738

E: sales@totalcubicles.co.uk

Volante Colour Options




Units 5-7, Luton Street
Liverpool
L5 9XR

T: 0844 800 7785
F: 0844 800 7738
E: sales@totalcubicles.co.uk

Vanity Units


The Volante Range of vanity units has an exceptional resistance to water and impact and is available in matching colours to the Volante range of cubicles.



Vanity Unit Layout Options


Standard Vanity Unit

VOLVSTD




Semi-recessed Vanity Unit

VOLVSR




Standard Vanity Unit with Loose Upstand

VOLVSTDLU




Semi-recessed Vanity Unit with Loose Upstand

VOLVSRRLU




Standard Vanity Unit with Coved Integral Upstand

VOLVSTDCU



Semi-recessed Vanity Unit with Coved Integral Upstand

VOLVSRRCU



Units 5-7, Luton Street
Liverpool
L5 9XR

T: 0844 800 7785

F: 0844 800 7738

E: sales@totalcubicles.co.uk


IPS Units

The Volante range of IPS units has an exceptional resistance to water and impact.




IPS Layout Options

Free Standing (FS)



Open Ended Left (OELH)



Open Ended Right (OERH)




Hole In Wall (HIW)




Panel Options

Postformed - available on parallel edges only



PVC



Units 5-7, Luton Street
Liverpool
L5 9XR

T: 0844 800 7785
F: 0844 800 7738
E: sales@totalcubicles.co.uk

Installation Instructions


Please look over the enclosed drawings to familiarise yourself with the parts required to construct your cubicle. Check that the sizes you have provided for manufacture are correct and match the sizes on site.

Installing The Partitions

Please Note: We no longer pre-drill the partitions as Soil Stacks and Window Placements can compromise the fitting position. Normally our Cubicles are divided equally along the wallspace except where Ambulant or Disabled Cubicles are to be implemented.


Step 1

Fix the partition channel brackets to the rear wall using 35x4mm posi screws and red plugs.




Step 2

The partitions should be set up 135mm off the floor on the adjustable leg provided. Tighten the Allen Head Clamp down securely on the partition.



Step 3

Next check the squareness of the partition and then fix the height adjustable leg to the floor with 35x4mm posi screws and red plugs, (please ensure before drilling that no under floor heating is present).




Installing Pilasters

Step 4

Start by installing an end pilasters back to the wall on the brackets provided, using 35x4mm posi screws and red plugs.


Set the pilaster height 135mm up from the floor to match the partition height and tighten the T-Nuts down securely on the pilaster.



Step 5

Fit the channel brackets centrally to the back of the centre pilaster, pilot the holes 10mm deep and fix with 20x4mm B2P screws.


Fit the pilaster by bolting through with the T-Nuts provided. Tighten securely with an Allen Key.



Check Measurements

Step 6

Next, measure the door aperture; it should measure 35mm less than the overall width of the door. If this matches, you can continue on, installing the remaining centre pilasters, again checking the aperture and measurements as you go.



Units 5-7, Luton Street
Liverpool
L5 9XR

T: 0844 800 7785
F: 0844 800 7738

E: sales@totalcubicles.co.uk

Installation Instructions


Please look over the enclosed drawings to familiarise yourself with the parts required to construct your cubicle. Check that the sizes you have provided for manufacture are correct and match the sizes on site.

Fit The Channel Headrail

Step 7

The Channel headrail is what braces the whole cubicle construction, so correct fitment of this item is essential. Start by cutting the headrail to the correct length. Next, fit the rail over the pilasters between the partitions using 35x4mm screws.

Pre-drill the pilasters through the top of the headrail and affix 3 15x4mm screws into the top of each pilaster bracing the construction.




Fitting The Doors And Lock Keeps

Step 8

The doors provided should overlap the aperture by 35mm. The door should now be fitted ensuring an equal overlap of 17.5mm on either side of the pilaster/aperture.

Use the 25x4mm screws piloted to a depth of 20mm to fit the hinges and 25x4 screws piloted to 20mm deep to fit the lock back plate assembly. Next fit the lock keep on the pilaster with 25x4mm screws.

Please Note: The nylon cams in the hinges can be adjusted to allow the door to swing open or closed. To change the operation of the closure, remove the nylon cam and turn in through 90 degrees. The locks are also symmetrical and can be used on either side of the door.



Accessories

Step 9

Fit the hat, coat hook and toilet roll holders at the desired height using the 20x4mm B2P screws piloted to 15mm depth.

Please Note: We can, upon request, provide T-Nuts so the hinges and pillaster are bolted through. This is sometimes a more robust solution when vandalism is prevalent, though standard construction is aesthetically more pleasing to look at than the bolt through option.

